

## Single-phase inverters can be connected in parallel

Inverters can be connected in parallel to increase the available output power. This is done by connecting the positive terminal of one inverter to the negative terminal of another ...

