



Battery cabinet work step settings

How do I install a battery cabinet?

Roll the battery cabinet to the area where the battery cabinet is to be installed. Secure the battery cabinet position by lowering the leveling feet until the cabinet is not resting on the casters and the cabinet is level.

NOTE supplied with two cosmetic covers. Additional battery cabinets are supplied without cosmetic covers.

Where do I install a line-up and match Battery Cabinet?

Line-up-and-match battery cabinets are installed adjacent to the UPS. The recommended installation location is on the right side of the UPS cabinet as viewed from the front of the cabinet. See Figure 3 for line-up-and-match configuration views. Figure 3. Eaton 93PM 100 kW UPS and Two 93PM Integrated Battery Cabinets

How is a ups cabinet installed?

Each cabinet in the battery system is placed in its correct location. cabinet grounding/mounting kit is installed between any cabinets that are bolted together. ground wire is installed between all cabinets. All conduits and cables are properly routed to the battery cabinets. ground conductor is properly installed to the UPS cabinet.

How do I connect a 1085hr battery to a mating cabinet?

Connect the top and bottom tray connectors to the mating cabinet connectors to complete the battery string connections (see Figure 4-13). FOR 1085HR ONLY: Connect the string of battery trays by mating the loose black connector with the blue locking mechanism from each tray to the fixed black connector mounted on the front edge of the tray below.

How do I install a 9395 model 1085 Battery Cabinet?

The 9395 Model 1085 battery cabinet is designed to be installed in a standalone configuration using two to four battery cabinets. Power wiring is installed externally between each battery cabinet and the UPS or battery disconnect using conduit. Battery cabinets may be installed adjacent to the UPS or in a separate location.

Where is the battery cabinet located?

The battery cabinet may be located to either the right or left of the UPS cabinet. The recommended location is to the right of the UPS cabinet. This procedure assumes the battery cabinet is located to the right of the UPS cabinet. 21.

Internal battery strapping must be verified prior to moving a battery cabinet (after initial installation). Battery cabinets contain non-spillable batteries. Keep units upright. Do not stack. ...

Web: <https://edukacja-aktywna.pl>

